

BI-PARTING SELF CLOSING SLIDER

TROUBLE SHOOTING PROCEDURES

Trouble	Probable Cause	Probable Solution
Doors are not Closing	<ol style="list-style-type: none"> 1. Door Dragging 2. Unit installed out of square 3. Door obstructed 4. Defective side rail 5. Door guide worn or bent 6. Defective cable assembly' 7. Weight stuck 8. Magnet in hold-open position 	<p>Adjust door or door bracket</p> <p>Contact construction company</p> <p>Check locks or remove obstruction</p> <p>Replace or oil slide rail</p> <p>Replace with new door guide</p> <p>Replace with new cable assembly</p> <p>Check for obstructions and remove</p> <p>Place magnet cap over magnet</p>
Doors are not Opening	<ol style="list-style-type: none"> 1. Door locked 2. Counter weight obstructed 3. Defective side rail 4. Defective cable assembly 	<p>Check locks and auto lock handle</p> <p>Check for and remove obstructions</p> <p>Replace or oil slide rail</p> <p>Replace with new cable assembly</p>
Doors not Staying Open	<ol style="list-style-type: none"> 1. Broken Magnet 2. Door stop bracket need adjusted 	<p>Replace magnet</p> <p>Readjust the bracket to magnet</p>
Only one Door Closes or Opens	<ol style="list-style-type: none"> 1. Broken cable assembly 2. Doors not centered 	<p>Replace roller to roller assembly</p> <p>Realign doors and cables</p>